



2601 Niagara Lane Plymouth, MN 55447 (763) 694-2614 (763) 553-1093 Fax

LIFEPOINT™ STANDARD & LIFEPOINT™ DELUXE INSPECTION PROTOCOL

OSHA requires that safety equipment be inspected before every use or work shift to ensure all components are in structurally sound condition and remain set up according to manufacturer's instructions. Perform the inspection steps listed below before attaching yourself to this unit. Inspections should be completed by a competent person capable of identifying structural deficiencies with a thorough knowledge of system components.

CHECKLIST: DATE: _____ INSPECTOR: _____

DATE: _____ INSPECTOR: _____

DATE: _____ INSPECTOR: _____

DATE: _____ INSPECTOR: _____

DATE: _____ INSPECTOR: _____

- ☐ 1). Ensure Weight Box is not damaged and there are no broken welds.
- ☐ 2). Ensure the correct number of Garlock-supplied counterweights are ready to load into Weight Box.
- ☐ 3). Turn the Anchor on its side (after removing Weights) and examine plastic coating on bottom of Weight Box. It must be free of embedded material, gouges and any loose areas.

*Please contact factory for replacements as required.

The Following Steps Apply Only to the LifePoint™ Deluxe:

- ☐ 5). Check all Set Collars holding the Tires and Weight Box to the Frame. They must be securely attached to Axle and Pivot Rod.
- ☐ 6). Check the Cotter Pins securing the front Tires to the Axles. They must be in place and in good condition.
- ☐ 7). Check Cable connected to Red Lever. It must be securely attached at both ends. Lever must move freely and release Pawl from Ratchet Teeth.
 - i). If Cable needs to be adjusted, make adjustment at lever end. Using two ½" wrenches, loosen top nut to free cable for adjustment.
 - ii). Turn bottom nut towards handle to tighten Cable or away from handle to loosen Cable. Tighten top nut to secure Cable to Bracket.
- ☐ 8). Remove Red Cover and inspect Ratchet Teeth and Pawl for wear.